




Pos	Part Number	Description	Additional Text	Quantity
1	79234005133	SHIFT SHAFT CPL.		1.00
2	79234008144	SLIDING PLATE CPL.		1.00
3	56534013100	TENSIONING SPRING 0,8MM		1.00
4	54634020000	SPRING GUIDE		1.00
5	54834014000	RETURN SPRING 03		1.00
6	54634050000	STOP DISK 14X30X1	EXHAUST	1.00
7	54632095000	needle sleeve HK 1412 14x20x12		2.00
8	0760142460	radial shaft seal 14x24x6 B		1.00
9	79234031100	Shift lever compl.		1.00
10	50233041500	PAIR NORDLOCK WASHER M6		1.00
11	0024060156S	HH collar screw M6x15 TX30		1.00

12	79234003000	SHIFTING FORK 1ST/3RD GEAR		1.00
13	79234002000	SHIFTING FORK 2ND GEAR		1.00
14	77034019000	SHIFTING MAIN L=93MM 05		1.00
15	0402061480	NEEDLE ROLLER DIN5402 6X14,8		3.00
16	0012060303S	Cap head screw M6x30-8.8		1.00
17	79234015100	Shift star cpl		1.00
18	0625618050	BALL BEARING 61805 C3		1.00
19	79234012000	SHIFT ROLLER 5G		1.00
20	79234012010	FRICTION BEARING CONTROLLER		1.00
21	79234012020	Magnet bracket cpl.		1.00
22	79211023000	gear position sensor		1.00
23	0984050143S	CYL. SCREW DIN6912 M5X14 8.8		2.00
24	0025050256S	HH collar screw M5x25 TX30		1.00
25	0021050003	washer DIN 9021 A - 5.3		1.00
26	79234024044	LOCKING LEVER CPL.		1.00
27	54634052300	SLEEVE FOR LOCKING LEVER		1.00
28	54834023000	LOCKING LEVER SPRING 03		1.00
29	54834019000	SHIFT. RAIL MAIN SHAFT 250/300		1.00
30	79234001000	SHIFTING FORK 4TH/5TH GEAR		1.00
31	A46011024000	Shield gear position sensor		1.00